

# PREDATOR V F3F SETTINGS

Settings is a personal thing, so read these instructions as a guide.

## **Aileron:**

Outer at tip 10 mm up in highrate / 8 mm lowrate.

Inner at fuselage (flaps) 3 – 5 mm up in highrate / 0 mm in lowrate.

Outer at tip 3 - 4 mm down in highrate / 2- 3 mm in lowrate.

Inner at fuselage 0 mm down in highrate / 0 mm in lowrate.

## **Elevator:**

Elevator 10 mm up in highrate / 8 mm lowrate

Elevator down 7 – 8 mm highrate / 6 mm down

## **Flightmode 2 – Speed:**

Not necessary in normal conditions.

Flaps at fuselage 1, 5 mm up

Aileron at tip 0,5 mm up

## **Flightmode 3 Launch / Thermal:**

Flaps at fuselage 6 mm down

Aileron at tip 1 mm down

Elevator 0,5 - 1 mm down.

## **Flaperonmix:**

Flaps 5 mm down at fuselage

Aileron 1,5 - 2 mm down at tip

Both setting are at max elevator throw.

## **Butterfly / Crow**

Flaps at fuselage 60 mm down

Ailerons at tip 6 mm up

Elevator 3 - 4 mm down

Also set down max on elevator at 45 degree flaps, and reduce elevator a bit at max flaps if possible. This is to prevent ballooning when lowering the flaps.

## **V tail /Rudder**

5 mm left / right at bottom of V.

## **Center of Gravity (CG)**

110 – 115 mm from leading edge, measured at root of the wings.

Regards

Gudmund Malones